

## SCIENCE TECHNICS SDN BHD

NO. 16 JALAN WAWASAN 1/KU7 SUNGAI KAPAR INDAH 42200 KLANG SELANGOR DARUL EHSAN MALAYSIA

TEL: 603 - 3291 7001, 3291 7009, 3291 7012 FAX: 603 - 3291 0809

Website: www.sciencetechnics.com.my Email: stsb@sciencetechnics.com.my

## OATS BEVERAGE ENZYME BLENDS ST

During the production of Oat Beverage it is common to see sedimentation as problem in the finished product.

This sedimentation is often due to insoluble complex carbohydrates precipitating out.

It has been found that a blend of amylases helps reduce this sedimentation.

Packaging Oats Beverage Enzyme Blends ST is packed in 10kg plastic lined

carton boxes.

**Dosage** 0.5 - 1g per kg oats

**Procedure** The enzyme is added to ground oats suspended in water.

Stir till dissolved.

Heat to 70°C, hold for 1 hour

Heat to 90°C for 10 minutes to inactive enzyme.

Storage Store in a cool, dry place

(January 2022)